

OPPO TUBE MOD WITH EXTERNAL POWER SUPPLY INFORMATION SHEET

- 1. How do you hook up the Oppo and external power supply?

 Plug a power cord into both the Oppo player and the external power supply. Connect the XLR terminated umbilical between player and power supply.
- 2. What sequence do you turn on each unit and what should you expect? First, turn on external PS 9.0 and then the Oppo player. There should be approximately a 45 second delay, where the external power supply is warming up the tubes.
- 3. What tubes are included with the Oppo and external power supply? What is their longevity? The Oppo has (2) new production JJ Electronic 6922 driver tubes. Driver tubes should last 6000 hours+.

The external PS 9.0 has (1) 5AR4 or equivalent 5U4-GB rectifier tube. Rectifier should last 10000 hours +.

4. Is there any other important information regarding the operation of the Oppo and external power supply?

Power supply powers tube stage only and may be turned off when not in use, while player may remain on if desired.