



## SONY XA5400ES TUBE MOD WITH EXTERNAL POWER SUPPLY INFORMATION SHEET

1. How do you hook up the Sony and external power supply?

**Plug a power cord into both the Sony player and the external power supply. Connect the XLR terminated umbilical between player and power supply.**

2. What sequence do you turn on each unit and what should you expect?

**First, turn on external PS 9.0 and then the Sony player. There should be approximately a 45 second delay, where the tube stage will remain muted while the voltages stabilize. After this, music may be played.**

3. What tubes are included with the Sony and external power supply? What is their longevity?

**The Sony has (2) new production Tung-Sol or Electro Harmonix 6SN7 driver tubes. Driver tubes should last 6000 hours+.**

**The external PS 9.0 has (1) Sovtek 5AR4 rectifier tube. Rectifier should last 12000 hours +.**

4. Is there any other important information regarding the operation of the Sony and external power supply?

**The PS 9.0 powers the tube stage only and may be turned off when not in use, while the Sony player may remain on if desired.**